

Spiral-blade stabilizer (modification: collar-collar) of KS type and straight-blade stabilizer of KP type

are used for borehole expansion and calibration according to the bore bit diameter at drilling in soft, intermediate, hard, low abrasive and abrasive rock.



Spiral-blade stabilizer (modification collar-pin) of KS type and straight-blade stabilizer of KP type

are used for string walls calibration to the nominal diameter in case the rock destruction tool is worn, and also used for centralizing and improving rock destruction tool working conditions at drilling in soft, intermediate, hard, low abrasive and abrasive rock.



Our enterprise produces centralizers with the full thread sizes from 98.4 mm to 660.6mm of 2500 mm in length and with the screw according to the customer requirements.

Centralizers can be made as integral blade construction (body and blade are solid unit) and as welded construction (the blades are welded to the body).